

Thank-you for choosing the Vandersteen Model 3A loudspeaker system. With proper care, your new speakers will provide many years of trouble free, high-quality sonic enjoyment.

The Model 3A is a high-technology product; we recommend that you carefully read this entire manual prior to connecting or using your new loudspeakers.

Vandersteen Audio

The Vandersteen Audio Model 3A is a floor standing dynamic loudspeaker developed and refined by almost twenty years of advanced research into loudspeaker design. Engineering, construction, and materials far exceeding industry standards have resulted in a reference quality level of performance unmatched even by larger and more costly designs.

The Model 3A is a worthy addition to any high quality music or audio/video system. The innovative first order crossover supports either bi-wire or vertical bi-amp connection. Superb dynamic and transient

response guarantees superior performance from records, CDs, video tapes, and laser discs. Custom engineered drivers, built exclusively for Vandersteen Audio, are aligned in a boxless design to maximize each driver's accuracy and musicality. An aesthetically pleasing appearance, incorporating an acoustically transparent grille and an audibly vented top, allows the Model 3A to compliment the decor of your home.

The Vandersteen Audio Model 3A is designed and built in the United States of America.

Contents

Connections	2	Contour Controls	11
Overview	2	Specifications	11
Bi-Wire	3	Associated Equipment	12
Vertical Bi-Amp	4	Amplifier Requirements	12
Mono-Wire	5	Components	12
Speaker Set-Up	6	Cables	12
Listening Height	6	A/V Considerations	13
Speaker Placement	7	Model Three Care	13
Odd Dimensions	7	Maintenance	13
Third Dimensions	9	Service	13
Acoustical Center	9	Support	13
Toe-In	9	Packing Instructions	14
Acoustic Treatments	10	Warranty Information	15
Placement Hints	10		

MODEL 3A SIGNATURE LOUDSPEAKER OPERATION MANUAL

The Model 3A contains protection circuits that track voice coil temperatures and reduce the current from your amplifier to one or more of the drivers if excessive temperatures are detected. When these devices are activated, the sound of the speaker will change and warning lights behind the front grille will glow. If this occurs, immediately reduce the volume level to allow the components in the speaker to cool down.

Please remember that no protection circuits are 100% effective and that repeated activation could cause the circuits to fail.

Do not connect the speaker wires until the cones and rear braces have been installed according to the instructions included with the braces.

CONNECTING THE MODEL 3As

The Model 3As are optimized for bi-wiring or vertical bi-amplification. Separate heavy-duty screw terminal inputs for the bass portion and tweeter-midrange portion of the crossover are located on the rear of each speaker.

BI-WIRING

Bi-wiring uses two speaker cables to connect each speaker to the amplifier. The speaker's internal crossover presents different electrical characteristics to each cable so that one cable carries the signal going to the woofers while the other cable carries the signal going to the midrange and tweeter. The improvements offered by bi-wiring versus a conventional single run of cable can be substantial. They are often large enough that a bi-wire set of moderately priced cable will sound better than a single run of far more expensive cable.

All the speaker cables in a bi-wire set should be the same. While it may be tempting to mix different models of cable to have a cable known for good bass response on the woofers and a different one known for good treble response on the midrange and tweeter, the differing sonic characteristics of the two cables can seriously affect the blending between the woofer and the midrange. The imaging of the speakers may be vague, transparency may be lost and detail and clarity can suffer.

Research has revealed that much of bi-wiring's benefit comes from the physical separation of the bass cable from the midrange/tweeter cable. Four conductor bi-wire cables that combine the wires together in one sheath are better than mono-wiring with an equivalent two-conductor cable, but they do not offer the full advantages of true bi-wiring.

BI-AMPLIFICATION

The Model 3As can only be bi-amplified passively

with two identical stereo amplifiers, preferably in a vertical configuration. (One stereo amplifier per speaker.) For Model 3A owners that already own two identical stereo amplifiers or can easily acquire a second stereo amplifier that matches the one they have, bi-amplification may offer some advantages over bi-wiring. It should be noted however, that bi-amplification usually offers only slight to moderate sonic improvements over bi-wiring so two lesser amplifiers will normally not outperform a single better amplifier. Unless you already have two identical amplifiers or easy access to a second matching amplifier, you are better off investing in the best single amplifier within your budget rather than dividing your budget between two less expensive and inferior sounding amplifiers.

When bi-amplifying, the speaker's internal passive crossover divides the frequencies by presenting different electrical characteristics to each channel of the amplifier. An electronic crossover is not used since the passive crossover in the Model 3A cannot be bypassed. Use of an electronic crossover would result in the two crossovers acting in series and would cause severe phase shift and response non-linearities.

The Model 3As should not be bi-amped with two different amplifier models in a horizontal mode. (One amplifier driving the woofers and the other amplifier driving the midrange and tweeter.) When half of the speaker is driven by a different amplifier model than the other half—and in these cases, usually by amplifiers chosen for the differences in their sounds rather than the similarities—the blending between the woofer and midrange is compromised and the sonic consistency of the speaker is affected. The upper and lower halves of the speaker will exhibit different dynamic characteristics, imaging characteristics, tonal balances and degrees of detail. This will cause considerable sonic confusion through the middle frequencies.

It is easy to connect a cable out of phase when using this connection method. Carefully verify cable polarity at speaker and amplifier.

Bare wires should never come into contact with the aluminum dress plate while the amplifier is on. Amplifier damage could result.

The input screws should be snug, but should not be overtightened.



BI-WIRE CONNECTIONS

Bi-wiring provides the sonic attributes of bi-amping without the cost and complexity of two stereo amplifiers. Bi-wiring is recommended for all systems using a receiver, integrated amplifier or single stereo amplifier. Four identical runs of equal length speaker cables are required. (Two per speaker.)

1. Crimp and solder spade lugs to the speaker ends of the cables being used to connect the Model 3As.
2. Choose one of the cables as the tweeter/midrange cable. Connect the ground side of the chosen cable under the top left terminal screw and the positive side of the cable under the top right terminal screw.
3. Connect the ground side of the remaining cable under the lower left terminal screw and the positive side of the cable under the lower right terminal screw.
4. Connect both cables in proper polarity to the same set of outputs on your amplifier. If possible, use only one spade lug to connect both cables to each terminal on the amplifier as shown in the enlarged view of an amplifier connection.

FOR BETTER SOUND


- a. All four speaker cables should be the same type and length. While certain different cable types may work well together, using identical cables on the top and bottom insures perfect blending.
- b. Use high quality cables and spade lugs. Crimp and solder the spade lugs to the cables.
- c. If your amplifier has "A" and "B" outputs, use the "A" outputs for both cables. The two sets of outputs may not be electrically identical.
- d. If your amplifier has multiple impedance taps, both cables should be connected to the same tap.



This connection method can only be used in a system configured with two identical stereo amplifiers.

Bare wires should never come into contact with the aluminum dress plate while the amplifier is on. Amplifier damage could result.

The input screws should be snug, but should not be overtightened.




VERTICAL BI-AMP CONNECTIONS

Vertical Bi-amplification uses a stereo amplifier to drive each speaker. Four identical runs of equal length speaker cables are required. (Two per speaker.)

1. Connect two cables to each speaker as described in steps 1-3 on the previous page.
2. Designate one stereo amplifier as the left channel amplifier and the other identical stereo amplifier as the right channel amplifier.
3. Use high quality single female to dual male "Y" connectors to connect the preamp's left channel output to both inputs of the left amplifier and the preamp's right channel output to both inputs of the right amplifier as shown in the diagram.
4. Connect the bass cable from the left speaker to one output channel of the left amplifier and the tweeter/midrange cable from the left speaker to the other output channel of the same amplifier.
5. Connect the bass cable from the right speaker to one output channel of the right amplifier and the tweeter/midrange cable from the right speaker to the other output channel of the same amplifier.

FOR BETTER SOUND

- a. Verify with the amplifier manufacturer that your amplifiers are the same generation and sound the same.
- b. If your amplifiers have multiple impedance taps, both cables should be connected to the same rated taps.
- c. All four speaker cables should be the same type and length. While certain different cable types may work well together, using identical cables on the top and bottom insures perfect blending.



The performance of the Model 3As is compromised by a mono-wire connection. They should be bi-wired as soon as possible.

Bare wires should never come into contact with the aluminum dress plate while the amplifier is on. Amplifier damage could result.

The input screws should be snug, but should not be overtightened.



MONO-WIRE CONNECTIONS

Mono-wiring should only be used with the Model 3As as a temporary connection method. The speakers should be bi-wired as soon as possible.

1. Cut two sections of wire about 2½ inches long to make two jumper wires.
2. Crimp and solder spade lugs to all four ends of the two jumper wires.
3. Connect one end of a jumper wire under the top left terminal screw and one end of the other jumper wire under the top right terminal screw.
4. Crimp and solder spade lugs to the speaker ends of the cable from the amplifier.
5. Connect the ground side of the speaker cable and the jumper cable from the top left terminal screw under the lower left terminal screw.
6. Connect the positive side of the speaker cable and the jumper cable from the top right terminal screw under the lower right terminal screw.
7. Connect the speaker cables to your amplifier, ground to ground and positive to positive.

FOR BETTER SOUND

- a. The speaker cables should be as short as possible and the same length. Consider putting the amplifier between the speakers rather than off to one side.
- b. Use quality cables. Keep all connections clean and tight.
- c. Bi-wire or bi-amplify as soon as possible for optimum performance.





SETTING-UP THE MODEL 3As

LISTENING HEIGHT

All properly aligned loudspeakers have a vertical listening window where their sound is optimized. The Model 3A's six inch high optimum listening window is centered at 35 inches when the speakers are vertical. If your ear height is above 35 inches at your normal listening position, the speakers should be leaned back to raise the optimum listening window up to your ear height. The chart to the right shows how much the speakers should be leaned back for different ear heights and listening distances.

1. Measure the distance from the listening position to the speakers and the height of your ears when you are seated at your listening position. (Ear height is roughly equal to the height of the tip of your nose)
2. Find the values closest to your actual measurements on the chart to the right.
3. Follow the horizontal line across from your listening distance and the vertical line up from your ear height to the point where they intersect. The heavy lines numbered from 0 to 2½ indicate how many inches the top of the speaker should be behind the bottom of the speaker to center the listening window at your listening height and distance.
4. Adjust the length of the spike or cone on the rear brace of each speaker to lean the speakers back the proper amount.
5. As an example of how to measure for the proper amount of lean:
 - a. Tie a nut to a piece of thread about five feet long.
 - b. Hang the thread and nut from the back of the speaker and measure the distance the nut is away from the bottom of the speaker as shown in the diagram. This measurement is the amount of speaker lean. (For clarity, the amount of lean in the diagram has been exaggerated and the rear brace is not shown.)
 - c. Secure the rear spike or cone.

Distance From Speakers In Feet



The Model 3As break-in and significantly improve during the first 100 hours of use. Until this period has elapsed, the speakers exhibit some sonic aberrations as the parameters of the Model 3A were established with completely broken-in drivers.

One way to speed-up the break-in process is to let the system play at a moderate volume level 24 hours a day for a week or so. Playing the speakers louder than a moderate level will not shorten the break-in period.

Vandersteen speakers will produce excellent, satisfying sound placed almost anywhere in a room. With all the possible variables in room layout, there are no magical formulas for determining the best speaker placement in every room. Since every room is different, we recommend that you try the speakers in every domestically acceptable location to find where they sound the best in your particular listening environment. The following sections contain suggestions that may be helpful in your placement experiments.

SPEAKER PLACEMENT

Problems can arise when you attempt to place a given loudspeaker, either front radiating or dipole, into a typical domestic environment. These problems are a function of the physical dimensions of the room. The room's dimensions dictate where in the room a node or anti-node will occur. Frequency response dips and peaks caused by nodes and anti-nodes can easily overwhelm the inherent accuracy of a loudspeaker.

If, for example, you place a loudspeaker with excellent frequency response characteristics in the corner of a room, you will increase response below about 200Hz by 6dB. This particular condition is a worst case example, but similar conditions apply throughout the room to some extent.

ODD DIMENSIONS PLACEMENT

Research on speaker placement has produced a method for reducing the nodes and anti-nodes in many rooms by positioning the loudspeakers on the odd dimensional intersections of the room. The odd dimensional intersections are the intersections of the imaginary lines you would draw if you divided the length of your room and the width of your room by odd numbers.

As an example, we will use a rectangular room measuring 14 feet wide by 18 feet long. We'll assume that you want to set the speakers on one of the short walls, although this method works equally well for long wall placement.

The first step is to take the length of the room, (18 feet in our example) convert it from feet to inches, (18 x 12 = 216) and divide the result by odd numbers.


- 216 divided by 3 is 72 (all to the nearest inch)
- 216 divided by 5 is 43
- 216 divided by 7 is 31
- 216 divided by 9 is 24
- 216 divided by 11 is 20
- 216 divided by 13 is 17

(And so on, eventually the lines start to pile on top of each other or the speaker runs into the wall.)

The results are the distances in inches that the

center of the speakers can be placed into the length of the room, away from the wall behind them, to minimize nodes and anti-nodes.

Now we can graph these odd dimensions distances on a drawing of the room. We only need to graph them for the wall where we intend to place the speakers.



We use the same method to figure how far the centers of the speakers should be from the side walls. We take the width of the room, (14 feet) convert it from feet to inches, (14 x 12 = 168) and divide the result by odd numbers.

- 168 divided by 3 is 56 (all to the nearest inch)
- 168 divided by 5 is 34
- 168 divided by 7 is 24
- 168 divided by 9 is 19
- 168 divided by 11 is 15

The results of these odd number divisions are the distances in inches that the center of each speaker can be placed into the width of the room, away from the side wall, to minimize nodes and anti-nodes.

Now we can graph these odd dimensions distances on a drawing of the room.



	15
	24
	34
	56
	56
	34
	24
	15

By overlaying the width and length graphs, we can see the intersection points of the lines. These points represent where the centers of the speakers should be placed to minimize nodes and anti-nodes.


					15
					24
					34
					56
					56
					34
					24
					15
	72	43	31	24	

As you can see, we now have quite a few intersections to choose from in our example room. Some of the intersections in your room will probably be eliminated by aesthetic or room function considerations, so you probably will not have as many.

As you try different placements for your speakers, always place both speakers on the same length line. For example, both speakers would be placed on the 43 inch line or both speakers would be placed on the 24 inch line. The speakers can be placed on different width lines, for example one on the 34 inch line and the other on the 56 inch line. Placing the speakers on different rather than matching width lines will require that the listening position be offset to center it between the speakers. Often, the bass response of the system will be slightly more linear with the speakers placed on different width lines, (asymmetrical placement) while the imaging will often be better with the speakers placed on matching width lines (symmetrical placement).



After listening to the speakers centered on the charted intersections, you should listen with the speakers a couple of inches away from the intersection points in each direction. In some cases, the speakers will sound better slightly off the intersections due to the particular characteristics of your room or a slight error in your original room measurements. Both speakers should be moved the same amount forward or backward when fine-tuning placement.




Several factors influence how speakers interface with a room other than the room's basic dimensions so it is possible that none of the placement options on the wall you initially place the speakers on will sound quite right. The sound may have too much or too little bass or be too forward or too withdrawn. If you are unable to achieve satisfactory sound with the speakers placed on one wall, try placing the speakers on another wall of the room. Even in a rectangular room, the speakers will interface differently with the room depending upon which of the four walls they are placed. In some rooms the speakers will sound best placed on a short wall while in other rooms the speakers will work better placed on a long wall.

THIRD DIMENSIONS PLACEMENT

A placement method that provides some unique effects is to place each speaker on the thirds of the room measurements and the listening position on the third of the length. The speakers are placed one third the length of the room from the wall behind them and one third the width of the room from the walls along side them. The listening position is then placed one third the length of the room from the wall behind it.

In our 14 by 18 foot example room, the thirds are 72 inches in the long dimension and 56 inches in the short dimension. The intersections of these measurements are used for third dimensions placement. In addition, the listening position is placed 72 inches from the rear wall of the room.




Both speakers should be tried up to two inches ahead and behind the intersections to determine if this improves the sound. Both speakers should be moved the same amount forward or backward.

Third dimensions placement reduces the interaction of the speakers with the room to an absolute minimum, but can create aesthetic or room function problems due to the speakers and listening position being so far out into the room. (The lower the odd number used to divide the room dimensions the lower the interaction between the speakers and the room.

ACOUSTICAL CENTER

The Model 3A's acoustical center is the physical center of the loudspeaker. In a perfect rectangular room with absolutely rigid walls and no doors or windows, the acoustical center of the loudspeaker would be placed exactly at the point where the two dimensions intersect to realize the full benefits of odd dimensions or third dimensions placement. In a real room, the actual best placement may vary from the intersection by as much as two inches or so. Fine-tuning the placement by moving the speakers a couple of inches off the odd dimension intersections takes these real world conditions into account.



No placement should be used that would place the acoustical center of the loudspeaker the same distance from the rear and side walls. The measurement from the center of the loudspeaker to the two walls should differ by at least two inches. If any of the odd dimension intersections are within two inches of the same distance from both the side and rear wall, those intersections should not be used.

SPEAKER TOE-IN

The degree of toe-in can affect the imaging and response characteristics of the speakers. In most rooms, the speakers will sound best facing straight ahead or slightly toed-in. Speakers that are placed close to the side walls or in rooms with very reflective side walls may require additional toe-in to avoid a confused image and/or a forward midrange and treble.


If the speakers need an excessive amount of toe-in to image properly or achieve good center fill, there may be a problem with the set-up or connection of the speakers or some part of the system may not be functioning as intended. To determine why the speakers require excessive toe-in, check all your speaker wire connections for correct phase and verify that the electrical components in the system are connected and functioning properly.

ACOUSTIC TREATMENTS


If the speakers are close to the side walls and you hear a brightness in the midrange/treble or a problem with the imaging that toeing-in the speakers does not help, some sound absorbent material should be

mounted on the side walls to control reflections.

To determine where the sound absorbent material should be placed, imagine that the walls are mirrors and mount the material on the walls where you would see the reflections of the speakers when you are sitting in your normal listening position. Before you actually mount anything on the side walls, experiment with a folded natural-fiber blanket to verify the positioning of the material and that you will get the results you desire.



If your listening position is close to the wall behind you, mount some sound absorbent material, such as a hanging tapestry, directly behind your head. As with the material for the side walls, experiment with a folded natural-fiber blanket to verify the results before you acquire or mount the material.



Bass problems that cannot be corrected with placement adjustments may be helped by the addition of bass traps or other bass control devices. Follow the instructions of the bass control devices as to their proper set-up and placement to correct the problems you are experiencing.

HELPFUL HINTS

- To try the speakers on different walls, set your equipment in the middle of the room so the speaker cables can reach each possible location.
- When you change the placement of the speakers, listen to several different pieces of music before judging the results of the change.
- If you set the speakers on a wood floor, place a coin under each cone or spike or use rounded head carriage bolts; 1/4-20 thread bolts in place of the cones and 3/8-16 thread bolts in place of the spikes.
- When you have discovered the optimum speaker positioning in your room, mark it with tape so you can move the speakers to vacuum without losing your placement reference.
- If the bass is ill-defined in your room regardless of where you place the speakers, check your windows for loose panes of glass. Loose glass will vibrate and can seriously impair the low frequency detail of the system.
- Don't over-analyse the sound of each placement. When the sound is right, it will be obvious.
- Keep notes on the sound of different placements you try. It is easy to get mixed-up and forget which placement sounded the best.

PLACEMENT NOTES

THE CONTOUR CONTROLS

Two contour controls are located on the aluminum dress plate at the rear of the Model Three. The upper control adjusts the tweeter level and the lower control adjusts the midrange level.

The contour controls can be used to compensate for a bright or dull room that can not be corrected with speaker placement, acoustical treatments or other passive means. The controls are limited in their effects and even at maximum rotation they will not take the response of the speaker out of a plus or minus 3dB envelope. Changing the contour controls will not affect

the detail, imaging or phase performance of the speakers due to the unique incorporation of the controls into the crossover circuitry.

When using the controls, we recommend that you start with small adjustments and only change the midrange controls or tweeter controls before listening to the effects of the change. By changing only one pair of controls at a time, you will be able to easily determine the effects that each pair of controls have upon the sound of the speakers in your room.

DESIGN AND SPECIFICATIONS

A precisely aligned dynamic design, blending common sense innovations with proven technology, gives the Model 3A many advantages:

- Computer optimized driver placement and cabinet design virtually eliminate the interference patterns usually associated with multi-way speakers.
- The lack of out-of-phase rear wave cancellations and interpanel interference allows many placement options in the listening room.
- The basic design concepts produce extended dynamic range and a point-source wave front for correct soundstage replication.
- The overall polar response pattern resembles the studio microphone pick-up pattern for better imaging and a broader listening area.
- High efficiency and a smooth impedance curve provide unlimited amplifier compatibility.

Acoustic Coupler: Long-throw, dual-spider active 10" with a critically damped ultra-rigid cone and heavy-duty 1.5" four-layer voice coil on a ventilated aluminum former. Range of operation: 26Hz to 35Hz

Woofers: Long-throw 8" with a die-cast basket and curvilinear polycone. 1.5 inch, two-layer voice coil on a ventilated aluminum former. 40 oz focused-gap magnet structure. Range of operation: 35Hz to 600Hz

Midrange: 4.5" with a patented, low-diffraction magnet and die-cast basket, linear surround and curvilinear polycone. Ferrofluid voice coil cooling. Range of operation: 600Hz to 5kHz

Tweeter: 1" critically damped, dual chamber metal alloy dome with ferrofluid voice coil cooling. Range of operation: 5kHz to 30kHz

Crossover: 600Hz and 5kHz. First-order, 6dB per octave. Dual inputs allow bi-wiring with a single stereo amplifier or passive vertical bi-amplification with two identical stereo amplifiers.

Impedance: 6 ohms nominal. 4 ohms minimum.

Efficiency: 88dB, 2.83 volt input at 1 meter.

Response: 26Hz to 30kHz \pm 3dB
30Hz to 22kHz \pm 1.5dB
By FFT step function.

Amplification: 100 to 200 watts per channel into 8 ohms. The amplifier should be stable into a 4 ohm load

Physical: 48" high x 16" wide x 10.25" deep. 89 pounds net, 102 pounds gross each.

Specifications and design subject to change without notice due to our continuing research and development programs.